

## **STRIPPER-200**

- APPLICATION:** Stripping agent for engraved screen for all mesh counts after Polymerization of emulsion
- DIRECTION OF USE:** Clean the Stripper tank, or it is remaining of the prior stripper in it than let it be add Stripper carefully, let the screens immersed up to 10 to 15 min. Rins the screen with plenty of water, degrease screen coating with emulsion.
- PRECAUTION:** Protect eyes, skin, clothes, breath (use of mask is necessary to protect the breathing) working room should be well ventilated, in case of an accident than contact immediately to physician. (Using a plenty of water works as first aid treatment)
- COLOR:** SLIGHTLY BROWN
- STORAGE:** 6 months ones it is opened.
- PACKING:** 35 Kgs. Blue H.D.P.E. Carboys